



## SAFE WORK PRACTICE

<b>TITLE</b>	Restricted Work Areas
<b>GENERAL</b>	Protecting workers from injuries associated with working in restricted areas
<b>APPLICATION</b>	A Work Area will be designated as a "Restricted Area", where there is a danger of contact with energized electrical equipment or hazardous substance.
<b>PROTECTIVE MECHANISMS</b>	Safe work procedures ERP (Emergency Response Plan ) PPE Permit system Hydrocarbon monitors Fire extinguishers Barricades and warning signs Lockout procedures
<b>SELECTION AND USE</b>	As per safe work procedures
<b>SUPERVISOR RESPONSIBILITY</b>	Supervisors are responsible to facilitate and/or provide proper instruction to their workers on protection requirements and training Designate limits of restricted area Hazard analysis Worksite inspection
<b>WORKER RESPONSIBILITY</b>	<ol style="list-style-type: none"><li>1. Establish and maintain clear exits.</li><li>2. Have safety and emergency breathing air apparatus available.</li><li>3. Place continuous gas monitors at strategic points.</li><li>4. Place fire extinguishers at strategic points.</li><li>5. Isolate system to be worked on.</li><li>6. Purge system.</li><li>7. Check for hydrocarbon leaks.</li><li>8. Ensure no alternate power sources.</li><li>9. Continually monitor area for changing conditions.</li></ol>

\* The information presented in this publication is intended for general use and may not apply to every circumstance. It is not a definitive guide to government regulations and does not relieve persons using this publication from their responsibilities under applicable legislation. The Alberta Construction Safety Association does not guarantee the accuracy of, nor assume liability for, the information presented here. Individual counselling and advice are available from the Association.